

RAPTOR®

TOUGH PROTECTIVE COATINGS

Products you will need



HOW TO PREPARE OEM PAINT



1 DEGREASE

Wash the surface to remove organic contaminants. Thoroughly degrease the substrate with a solvent-based degreaser such as U-POL WIPE#6 or System 20. This removes grease, dirt.



2 SAND

Abrade with P180.



3 ABRABE SURROUNDING AREA

Any hard to reach areas should be abraded by hand with a red scuff pad.



4 DEGREASE AGAIN

Once abraded, thoroughly degrease again.



5 WIPE WITH TACK RAG

Wipe the substrate with a tack rag.



6 APPLY RAPTOR

You are now ready to shoot RAPTOR.



TOP TIPS:



Masking is essential to eliminate the risk of overspray.



Any localised breakthroughs, apply 1-2 coats of RAPTOR Etch Primer. It can be painted over after 10-20 mins.



Bare plastic or hard to abrade areas require 1-2 coats of RAPTOR Adhesion Promoter. It can be painted over after 20 mins.



Invert the can to clear the dip tube in between coats.

WWW.RAPTORCOATINGS.COM

U-POL Ltd, 4th Floor, The Grange, 100 High Street, London N14 6BN.

T: +44 (0)20 8492 5900 E: uk.sales@u-pol.com

U-POL TECHNICAL SUPPORT:

+44 (0) 1933 230310