

RAPTOR®

TOUGH PROTECTIVE COATINGS



Products you will need

HOW TO SPRAY A BUMPER



1



DEGREASE
Degrease the substrate with a water-based System 20 degreaser.

2



SAND
Abrade with 180-240 grit.

3



DEGREASE
Degrease again.

4



WIPE SUBSTRATE
Wipe the substrate with a tack rag.



READ INSTRUCTIONS
After 20 mins, you are ready to shoot RAPTOR.

NOTES:
USE OF SOLVENT BASED DEGREASER CAN SWELL PLASTICS.



TOP TIPS:



An anti-static, anti-silicone degreaser that removes contaminants including wax, grease and silicones.



Good preparation is essential. Refer to "Substrate Preparation - Bare Plastic" video.



Any hard to reach areas should be abraded by hand with a fine scuff pad.



Bare plastic requires 1-2 coats of RAPTOR Adhesion Promoter. It can be painted over after 20 mins.

WWW.RAPTORCOATINGS.COM

U-POL Ltd, 4th Floor, The Grange, 100 High Street, London N14 6BN.
T: +44 (0)20 8492 5900 E: uk.sales@u-pol.com

U-POL TECHNICAL SUPPORT:
+44 (0) 1933 230310