

# RAPTOR<sup>®</sup>

## TOUGH PROTECTIVE COATINGS

Products you will need



### HOW TO PREPARE RUST



#### 1 SAND LOOSE RUST

Remove all loose rust or flaky material with a coarse abrasive or a grinder.



#### 2 SAND LIGHT RUST

Use a sander to remove any light rust or surface rust with coarse abrasive like 60-80 grit to remove any imperfections.



#### 3 DEGREASE

Once abraded, thoroughly degrease.



#### 4 ACTIVATE EPOXY PRIMER

Activate and apply RAPTOR Epoxy Primer according to the technical datasheet.



#### 5 APPLY EPOXY PRIMER

2-3 coats should be applied, with a gun, an aerosol or a roller.



#### 6 APPLY RAPTOR

From 60 mins after application of the final coat, up to 7 days, the Epoxy Primer can be directly overcoated with RAPTOR.



### TOP TIPS:



Grind or remove any rust with a coarse abrasive or a grinder.



Masking is essential to eliminate the risk of overspray.



RAPTOR Epoxy Primer can be applied with a gun, an aerosol or a roller.



RAPTOR 2K Epoxy Primer in aerosol can be useful for smaller areas.

[WWW.RAPTORCOATINGS.COM](http://WWW.RAPTORCOATINGS.COM)

U-POL Ltd, 4th Floor, The Grange, 100 High Street, London N14 6BN.

T: +44 (0)20 8492 5900 E: [uk.sales@u-pol.com](mailto:uk.sales@u-pol.com)

**U-POL TECHNICAL SUPPORT:**

**+44 (0) 1933 230310**